



CHAPTER

2

Have your phone play music instead of just ringing when someone calls



Melody Call

Application

Required

Monthly Charge

Basic Course

105 yen (including tax)

*For more details, refer to "Charges" on p. 34.

The information contained in this guide is intended for Basic Course subscribers.

This service replaces the ordinary ringback tone the caller hears when calling your mobile phone with a seasonally-based melody that changes each month. You can also change the melody to other sounds such as popular songs or humorous voices.

Apply Here



(in Japanese only)



From i-mode handsets



From smartphones

Uses:

Humorous Voice

Latest J-Pop



Friends



Your mobile phone



Other Callers

Service Features



Basic Course (Monthly Charge: 105 yen [including tax])

It's possible to set a great variety of melodies.

*You can purchase any of over 200,000 melodies provided on IP content providers.*1

*1 Charges for the Melody Call sound source usage apply separately for the use of melodies provided on IP sites. Charges for Melody Call sound source usage for different melodies may vary (some melodies can be set free of charge).

Change the melody according to who's on the other end of the line!

*You can register up to nine melodies in your Melody List.



New applications for the Enjoy Course (monthly charge: 210 yen [including tax]) are no longer accepted as of May 31, 2007. Subscribers already using the Enjoy Course may continue to use the service.

Recommended "Melody Sample" free during the month of registration!
Now try out songs from popular artists and humorous voice samples♪

You can sample selected Melody Call melodies with no usage charges required for the month of melody setting!*

- *1 Only one melody can be set per month per line subscribed. Additionally, the "Melody Sample" service cannot be used in the month immediately following the month during which the service is used.
- *If the "Melody Sample" setting for the selected melody is not cancelled during the month in which the setting was made, charges for use of the melody will apply beginning the following month.
- *The "Melody Sample" service is available through the IPs listed on the i-mode Menu List and the sp-mode dmenu.
- *For more details on "Melody Sample," check the IP site.



No usage charges for 31 days for first-time subscribers!!

The Basic Course monthly charge of 105 yen (including tax) will not be levied for a 31-day period starting on the day of application.

- This monthly charge exemption is also available to Option Pack Discount subscribers and customers changing their subscriptions from the Enjoy Course to the Basic Course.
- * Limited to initial subscriptions.
- * Upon expiration of the free usage period, charges will be applied unless the subscriber applies for cancellation of the service.
- * The packet communications charge, Melody Call sound source usage charge, and any other charges incurred during the use of the service still apply during the 31-day free period.
- * The 31-day free period will be terminated immediately if a change is made to the mobile phone subscription type (from FOMA to Xi, or Xi to FOMA), the subscription is transferred to another subscriber, or other changes are made during the free service period.

Starting Out

On an i-mode handset

All settings should be made while in i-mode.

For purchasing melodies from IP sites

Select "メロディコール" (Melody Call).

For setting and checking on the Melody Call Settings Site

Select "3 各種設定 (確認・変更・利用)" (Various Settings [Checking, Changes, Use]).

Select "メロディコール" (Melody Call) in the "各種サービス設定・確認 (オプション設定)" (Setting and Checking of Various Services [Options]).

Melody Call Settings Site (Basic Course)

*While no packet communications charges apply for accessing the Melody Call Settings Site in i-mode, packet communications charges do apply for accessing an IP site, the i-mode Menu site, or the Free Melody Corner.

Starting Out

On a smartphone

All settings should be made while in sp-mode.

For purchasing melodies from IP sites

Tap on "音楽 / メロディコール / ボイス" (Music/Melody Call/Voice) and select "メロディコール" (Melody Call).

For setting and checking on the Melody Call Settings Site

Select "各種設定の一覧を見る" (View Various Settings List).

Select "メロディコール" (Melody Call) in the "各種サービスの設定・確認 (オプション設定)" (Setting and Checking of Various Services [Options]) menu.

Melody Call Settings Site (Basic Course)

Using a Smartphone

Now you can download the Melody Call app from the dmenu!!

If using a smartphone, downloading the Melody Call app will allow you to easily access the Settings Site from the smartphone Handset App List.

Downloading the Melody Call app

- Select "一覧を見る" (View List) in the "サービス一覧" (List of Services) on the dmenu. → then select "メロディコール" (Melody Call).
- OR Select "お客様サポート" (Customer Support) from dmenu. → From "ドコモアプリ" (DOCOMO App) menu, select "インストール・アップデート" (Install/Update). → Select "メロディコール" (Melody Call).

*Use of Melody Call with a smartphone requires an sp-mode subscription.



The initial melody is set to play immediately upon subscription.*

*This also holds for new Melody Call subscriptions made through application for the "Option Pack Discount."



The initial melody is set in the Melody List at the time of subscription to Melody Call.

The initial melody is a mix of the ordinary ringback tone (typical ringing sound) and an original melody that changes automatically each month. For more details, refer to the update schedule below.

Initial Melody Update Schedule *Schedules are subject to change.

January (New Year time)	Dec.26-Jan.15	April (Spring)	Apr.1-Apr.30	July (Early summer)	Jul.1-Jul.31	October (Autumn)	Oct.1-Oct.31
February (Winter)	Jan.16-Feb.28	May (Late spring)	May 1-May 31	August (Summer)	Aug.1-Aug.31	November (Late autumn)	Nov.1-Nov.30
March (Early spring)	Mar.1-Mar.31	June (Rainy season)	Jun.1-Jun.30	September (Early autumn)	Sept.1-Sept.30	December (Christmas)	Dec.1-Dec.25

*To change the initial melody and register a new melody instead, refer to p. 20, 21.

*The above is an image of the i-mode screen.

Listen to sample melodies of Melody Call!


Even those customers who have not yet subscribed to "Melody Call" can also listen to sample melodies, enabling them to check out what melodies are available with the service before subscribing. Of course, current Melody Call subscribers can also listen to these melodies.

*Melody Call cannot be sampled without an i-mode or sp-mode subscription. *A dialing charge applies for "Sound Source Preview."
*You may not be able to sample certain melodies. *While no packet communications charges apply for accessing the i-mode Settings Site, packet communications charges do apply for accessing an IP site or the i-mode Menu site.

On an i-mode handset



On a smartphone



Registering a New Melody

Change the initial melody and register new ones.

*With the Basic Course, up to nine melodies can be registered simultaneously in addition to the ordinary ringback tone.

*Monthly charges for Melody Call sound source usage for melodies provided on IP sites apply as long as the melodies remain undeleted. When deleting melodies, refer to the "One-Point Advice" on p. 28 and p. 29.

*These cannot be registered by Enjoy Course subscribers. Registration of melodies provided on IP sites requires changing the subscription to the Basic Course.


*Contracts with the IP (content provider) are required to make the melody source registrations.

*Melody Call sound source usage charges for each melody are determined independently by the IPs (content providers) themselves; DOCOMO acts as an agent for collection of these charges. Users receive bills for these charges from NTT FINANCE CORPORATION on behalf of DOCOMO. Additionally, no prorated daily calculation is made, even when the subscriber purchases the service later in the month.

*Canceling the Melody Call subscription automatically cancels melodies provided on IP sites that you have already registered.

On an i-mode handset

To navigate to ① Melody Call Settings Site Select "お客様サポート" (Customer Support) from i-Menu. → Select "各種設定 (確認・変更・利用)" (Various Settings [Checking, Changes, Use]). → Select "メロディコール" (Melody Call).




This completes registration of the melody. Then, set the callers for who you want the Melody played. → p. 22, p. 24 and p. 26

On a smartphone

To navigate to Melody Call Settings Site **1** Select "お客様サポート" (Customer Support) from dmenu. → Select "各種設定の一覧を見る" (View Various Settings List). → Select "メロディコール" (Melody Call) from "各種サービスの設定・確認 (オプション設定)" (Setting and Checking of Various Services [Options]) menu.


*Those subscribers who have downloaded the Melody Call app from the dmenu can access the app list on their smartphone.




Select "メニューリスト" (Menu List) from the Settings Site.




Select the desired site.




Select a melody from the IP site, then after confirming the terms of use and precautionary notes, select "承諾して登録" (Agree and Register).




Select the folder to register the melody in, and then select "登録する" (Register).



Select "承諾して登録する" (Agree and Register), enter your sp-mode password, then select "決定" (OK).



[Random Play settings not available]



[Random Play settings available]

This completes registration of the melody. Then, set the callers for who you want the Melody played. → p. 23, p. 25 and p. 27


Setting a Melody That Everyone Can Hear (Setting My Usual Ringback Tone)

The melody set in "My Usual Ringback Tone" is heard by all callers.


*For specifying melodies for individuals, see to p. 26 and p. 27.

On an i-mode handset

If the melody has been set to the Melody List as described on p. 20 ...




Select "はい" (YES) in the "登録完了画面" (Complete Registration Screen).




This completes the "My Usual Ringback Tone" setting.

Setting From the Settings Site

If the melody has been registered to the Melody List as described on p. 20, you can also set it from the Settings Site.



Select "みんなに聴かせる (My通常音)" (For All Callers [My Usual Ringback Tone]) from the Settings Site.




Select the melody you want to set and select "設定" (SET).

Select "はい" (YES) on the "設定確認" (Settings Confirmation) screen to complete the "My Usual Ringback Tone" setting.




One-Point Advice

How do I confirm the status and histories of melodies I have set up this month?




If you want to check the status of your Melody List



The melody settings status is displayed.

If you want to check this month's history




The melodies set in the current month are displayed.


Melodies displayed in the history can be used any number of times within the current month only.

On a smartphone

If the melody has been set to the Melody List as described on p. 21 ...




Select "はい" (YES) in the "登録完了画面" (Complete Registration Screen).



This completes the "My Usual Ringback Tone" setting.

Setting From the Settings Site

If the melody has been registered to the Melody List as described on p. 21, you can also set it from the Settings Site.



Select "みんなに聴かせる (My通常音設定へ)" (For All Callers [To My Usual Ringback Tone Setting]) from the Settings Site.




Select the melody you want to set and select "設定" (SET). Select "はい" (YES) on the "設定確認" (Settings Confirmation) screen to complete the "My Usual Ringback Tone" setting.



One-Point Advice

How do I confirm the status and histories of melodies I have set up this month?




If you want to check the status of your Melody List



The melody settings status is displayed.

If you want to check this month's history



The melodies set in the current month are displayed.

Melodies displayed in the history can be used any number of times within the current month only.

Setting Random Play Function

This function lets you set the melodies played to callers in random order.


*Setting not available to Enjoy Course subscribers.

On an i-mode handset


To navigate to ① [Melody Call Settings Site] Select "お客様サポート" (Customer Support) from i-Menu. → Select "各種設定 [確認、変更、利用]" (Various Settings [Checking, Changes, Use]). → Select "メロディコール" (Melody Call).



Select "ランダム再生リスト" (Random Play List) from the Settings Site.




Select "楽曲や聴かせる相手の変更及び設定はコチラ" (Here to change and set melodies and callers to hear them).



Select "みんなに聴かせる" (For All Callers) or "特定の人に聴かせる" (For Individuals), then select "設定" (SET).


Select the melodies you want played in random order by placing a check in the check box to the left of the melody title.

When played for all callers




This completes the Random Play settings.

When played for individuals



Select the callers to be played the melodies in random order. Select the callers to whom you want random melodies played by placing a check in the check box to the left of the caller's name (phone number), then select "設定" (SET).

*You can also make settings for the Random Play function from "みんなに聴かせる (My通常音)" (For All Callers [My Usual Ringback Tone]) and "特定の人に聴かせる (My電話帳)" (For Individuals [My Phonebook]).



Setting "Random Play" is completed.


If you have selected Random Play in the "みんなに聴かせる (My通常音)" (For All Callers [My Usual Ringback Tone]) setting and then have changed it to "特定の人に聴かせる (My電話帳)" (For Individuals [My Phonebook]) setting, you will see the following notice: *My通常音はランダム再生から変更されておりません。下の [My通常音の変更] から楽曲を変更してください。 (*My Usual Ringback Tone is still in Random Play mode. Change it using the 'My通常音の変更' (Changing My Usual Ringback Tone.).)

*Actual screen may be different.


On a smartphone

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from dmenu. → Select "各種設定の一覧を見る" (View Various Settings List). → Select "メロディコール" (Melody Call) from "各種サービスの設定・確認 (オプション設定)" (Setting and Checking of Various Services [Options]) menu.


*Those subscribers who have downloaded the Melody Call app from the dmenu can access the app list on their smartphone.



1 Select "ランダム再生リスト" (Random Play List) from the Settings Site.




2 Select "ランダム再生設定" (Random Play Settings).



3 Select "みんなに聴かせる" (For All Callers) or "特定の人に聴かせる" (For Individuals), then select "設定する" (SET).


Select the melodies you want played in random order by placing a check in the left of the melody title.

When played for all callers




4 This completes the Random Play settings.

When played for individuals



4 Select the callers to be played the melodies in random order. Select the callers to whom you want random melodies played by placing a check in the check box to the left of the caller's name (phone number), then select "設定する" (SET).

*You can also make settings for the Random Play function from "みんなに聴かせる (My通常音設定へ)" (For All Callers [to My Usual Ringback Tone Setting]) and "特定の人に聴かせる (My電話帳へ)" (For Individuals [to My Phonebook]).



5 Setting "Random Play" is completed.


If you have selected Random Play in the "みんなに聴かせる (My通常音設定へ)" (For All Callers [to My Usual Ringback Tone Setting]) setting and then have changed it to "特定の人に聴かせる (My電話帳へ)" (For Individuals [to My Phonebook]) setting, you will see the following notice: "※My通常音はランダム再生から変更されておりません。下の [My通常音の変更] から楽曲を変更してください。" (*My Usual Ringback Tone is still in Random Play mode. Change it using the 'My通常音の変更' (Changing My Usual Ringback Tone).)

Setting Melodies for Specific Callers (Registering My Phonebook)

To allow different callers to hear different melodies, register them in "My Phonebook" (maximum of 100 entries). Setting up the individual caller allows the name (number) of the registered person to be displayed in the Phonebook.

On an i-mode handset

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from i-Menu. → Select "各種設定 (確認・変更・利用)" (Various Settings [Checking, Changes, Use]). → Select "メロディコール" (Melody Call).



1 Select "特定の人に聴かせる (My電話帳)" (For Individuals [My Phonebook]) from the Settings Site.



2 Select "新規番号登録" (Register New Number).




3 Input the information for the person to be designated and select the melody.

Input the phone number*1 and name of the person, designate the melody, and select "登録" (Register).

*1 Only mobile, PHS, and landline phones that support Melody Call listening are accepted.

*Only the number of the caller is displayed in the list screen if the number, but not the name, is registered in the phonebook.



4 Registration to My Phonebook and Setting Melody for a Specific Caller are completed.


*To continue registering other numbers, select "続けて登録" (Continue Registering).

*Registration to My Phonebook can be done easily by using your mobile phone's Phonebook Extract function at the screen in Step ③. See the user's manual for details.


On a smartphone

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from dmenu. → Select "各種設定の一覧を見る" (View Various Settings List). → Select "メロディコール" (Melody Call) from "各種サービスの設定・確認 (オプション設定)" (Setting and Checking of Various Services [Options]) menu.

*Those subscribers who have downloaded the Melody Call app from the dmenu can access the app list on their smartphone.



Select "特定の人に聴かせる (My電話帳へ)" (For Individuals [to My Phonebook]) from the Settings Site.




Select "新規番号登録" (Register New Number).



Input the information for the person to be designated and select the melody.

Input the phone number*1 and name of the person, designate the melody, and select "登録する" (Register).

*1 Only mobile, PHS, and landline phones that support Melody Call listening are accepted.
*Only the number of the caller is displayed in the list screen if the number, but not the name, is registered in the phonebook.



Registration to My Phonebook and Setting Melody for a Specific Caller are completed.

*To continue registering other numbers, select "続けて登録する" (Continue Registering).

*Registration to My Phonebook can be done easily by using your mobile phone's Phonebook Extract function at the screen in Step ③. See the user's manual for details.

Temporarily Deactivating and Reactivating Melody Call

When the service is temporarily deactivated, the ordinary ringback tone is played.

*The temporary deactivation is not a cancellation of service; the monthly charges and Melody Call sound source usage charges still apply for the duration of the temporary stoppage. When you choose to reactivate the service, the settings in effect prior to suspending the service are enabled.


On an i-mode handset

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from i-Menu. → Select "各種設定 (確認・変更・利用)" (Various Settings [Checking, Changes, Use]). → Select "メロディコール" (Melody Call).

If choosing "Temporary Deactivation"




Select "一時停止/開始" (Temporarily Deactivate / Activate) from the Settings Site.




Confirm the status and select "はい" (YES). Melody Call is now inactive.

*After suspending Melody Call, reactivate the service yourself.



When Melody Call is temporarily deactivated, this is indicated in the user's Melody Call Settings Site.

If choosing "Reactivate"



Select "一時停止/開始" (Temporarily Deactivate / Activate) or "開始の設定" (Activation Settings) from the Settings Site.




Confirm the status and select "はい" (YES). Melody Call is now active.


How do I delete melodies?

You can delete set melodies from the Melody List.


*Monthly charges for Melody Call sound source usage for melodies provided on IP sites apply as long as the melodies remain undeleted.



Select the melody from the "楽曲リスト" (Melody List) screen, then select "楽曲を削除" (Delete Melody) on the "設定状況" (settings status) screen.



Confirming the "削除確認" (Delete Confirmation) screen, and if you wish to proceed, select "はい" (YES).



The "削除完了" (Deletion Complete) screen is displayed.*

*A password confirmation screen is displayed for the melody provided on an IP site; enter your i-mode password and select "決定" (OK) to complete the deletion.

On a smartphone

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from dmenu. → Select "各種設定の一覧を見る" (View Various Settings List). → Select "メロディコール" (Melody Call) from "各種サービスの設定・確認 (オプション設定)" (Setting and Checking of Various Services [Options]) menu.

*Those subscribers who have downloaded the Melody Call app from the dmenu can access the app list on their smartphone.

If choosing "Temporary Deactivation"

1

Select "一時停止/開始" (Temporarily Deactivate / Activate) from the Settings Site.

2

Confirm the status and select "はい" (YES).
Melody Call is now inactive.

When Melody Call is temporarily deactivated, this is indicated in the user's Melody Call Settings Site.

If choosing "Reactivate"

1

Select "一時停止/開始" (Temporarily Deactivate/Activate) or "現在お客様はメロディコールを一時停止に設定しています。" (Customer currently has Melody Call deactivated) from the Settings Site.

2

Confirm the status and select "はい" (YES).
Melody Call is now active.

Changing or Deleting Registered Phone Numbers

Change or delete currently registered telephone numbers and others using "My Phonebook".

*Deleted numbers are no longer displayed.

On an i-mode handset

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from i-Menu. → Select "各種設定 (確認・変更・利用)" (Various Settings [Checking, Changes, Use]). → Select "メロディコール" (Melody Call).

1

Select "特定のの人に聴かせる (My電話帳)" (For Individuals [My Phonebook]) from the Settings Site.

2

Select the name (or the phone number) to be changed or deleted.

3

Select "変更" (Change) or "削除" (Delete).

When "変更" (Change) is selected

4

Input the new phone number, name, and the melody, then select "登録" (Register).

5

Complete registration changes.
Select "はい" (YES) to complete content registration changes.

When "削除" (Delete) is selected

4

Confirm the contents to be deleted.
Select "はい" (YES) to delete the registered content.

*Changes to and deletions from "My Phonebook" do not affect the content registered in the mobile phone's Telephone Book.

How do I delete melodies?

You can delete set melodies from the Melody List.

*Monthly charges for Melody Call sound source usage for melodies provided on IP sites apply as long as the melodies remain undeleted.

One-Point Advice

Select the melody from the "楽曲リスト" (Melody List) screen, then select "楽曲を削除する" (Delete Melody) on the "楽曲詳細設定" (Detailed Melody Settings) screen.

Confirming the "削除確認" (Delete Confirmation) screen, and if you wish to proceed, select "はい" (YES).


The "削除完了" (Deletion Complete) screen is displayed.*

*A password confirmation screen is displayed for the melody provided on an IP site; enter your sp-mode password and select "決定する" (OK) to complete the deletion.

On a smartphone

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from dmenu. → Select "各種設定の一覧を見る" (View Various Settings List). → Select "メロディコール" (Melody Call) from "各種サービスの設定・確認 (オプション設定)" (Setting and Checking of Various Services [Options]) menu.


*Those subscribers who have downloaded the Melody Call app from the dmenu can access the app list on their smartphone.



Select "特定の人の聴かせる (My電話帳へ)" (To My Phonebook) from the Settings Site.



Select the name (or the phone number) to be changed or deleted.




Select "内容を変更する" (Change Content) or "削除する" (Delete).

When "内容を変更する" (Change Content) is selected




Input the new phone number, name, and the melody, then select "登録する" (Register).



Complete registration changes. Select "はい" (YES) to complete content registration changes.

When "削除する" (Delete) is selected



Confirm the contents to be deleted. Select "はい" (YES) to delete the registered content.

*Changes to and deletions from "My Phonebook" do not affect the content registered in the mobile phone's Telephone Book.

Adding, Changing, and Transferring Callers


Select the incoming phone numbers you want to set or add to the Melody List from currently registered phone numbers in "My Phonebook." This process determines which caller will hear which melody.

On an i-mode handset

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from i-Menu. → Select "各種設定 (確認・変更・利用)" (Various Settings [Checking, Changes, Use]). → Select "メロディコール" (Melody Call).




Select "楽曲リスト" (Melody List) from the Settings Site.




Select the melody you want to set.

Select "楽曲リスト" (Melody List); the settings status is displayed. Select the melody you want to set.




Select "相手を変更" (Change Caller).

*If a melody is already selected as My Usual Ringback Tone and/or a "Random Play" melody, it may not be possible to select that same melody and to add, change, or transfer a caller for whom you want the melody played. If this occurs, that melody should be dropped from My Usual Ringback Tone and from the "Random Play List."



Select the caller. Place a check mark in the check box to the left of the caller's name (or number) that you would like to assign. Select "設定" (SET) when finished.

*A maximum of 30 callers can be assigned to one melody. If you want to assign more than 31 callers, either register the melody to "My Usual Ringback Tone" or set up another Melody List with the same melody. *Names (phone numbers) marked with an asterisk (*) already have a different melody set for them. You can change the settings by placing a check mark in the check box.




On the "設定確認" (Settings Confirmation) screen, select "はい" (YES) to complete the registration of the caller.

On a smartphone

To navigate to Melody Call Settings Site ① Select "お客様サポート" (Customer Support) from dmenu. → Select "各種設定の一覧を見る" (View Various Settings List). → Select "メロディコール" (Melody Call) from "各種サービスの設定・確認 (オプション設定)" (Setting and Checking of Various Services [Options]) menu.


*Those subscribers who have downloaded the Melody Call app from the dmenu can access the app list on their smartphone.




Select "楽曲リスト" (Melody List) from the Settings Site.



Select "詳細" (Details) for the melody you want to set.




Select "相手を変更する" (Change Caller).



Select the caller. Place a check mark in the check box to the left of the caller's name (or number) that you would like to assign. Select "設定する" (SET) when finished.

*A maximum of 30 callers can be assigned to one melody. If you want to assign more than 31 callers, either register the melody to "My Usual Ringback Tone" or set up another Melody List with the same melody.
Names (phone numbers) marked with an asterisk ("") already have a different melody set for them. You can change the settings by placing a check mark in the check box.



On the "設定確認" (Settings Confirmation) screen, select "はい" (YES) to complete the registration of the caller.

*If a melody is already selected as My Usual Ringback Tone and/or a "Random Play" melody, it may not be possible to select that same melody and to add, change, or transfer a caller for whom you want the melody played. If this occurs, that melody should be dropped from My Usual Ringback Tone and from the "Random Play List."

Charges

Application Required

Monthly Charge

● Basic Course

105 yen (including tax)

When purchasing other melodies provided on IP sites, the monthly charges for Melody Call sound source usage apply for each individual melody. No prorated daily calculation is made.

*A charge of 210 yen (including tax) applies to the Enjoy Course.
(New applications for the Enjoy Course are no longer accepted as of May 31, 2007.)

Charges for Settings

Packet communications charges apply when purchasing and setting melodies via i-mode or sp-mode. In addition, dialing charges do apply for Sound Source Preview.

*However, packet communications charges do not apply for packet communications made on the i-mode Melody Call Settings Site.

Notes on Use

● Functions and Operations

● Melody Call can be received by callers using the following phones:

- Mobile and PHS phones: DOCOMO (FOMA, Xi), satellite phones, au, SOFTBANK MOBILE, EMOBILE, and WILLCOM phones
 - Landline and public phones: NTT EAST, NTT WEST, NTT Communications, SOFTBANK TELECOM, SOFTBANK BB, KDDI, Jupiter Telecommunications Group, UCOM, FUSION COMMUNICATIONS, Kyushu Telecommunication Network, CHUBU TELECOMMUNICATIONS, K-Opticom, KVH, NTT Plala, NTT-ME, business mopera IP Centrex service (DOCOMO) phones
- For calls made from WILLCOM, landline and public phones, Melody Call begins to play after the connection announcement ("Your call is being connected."). For more details, please refer to the NTT DOCOMO website.

- All set melodies are cleared when the subscription is changed from the Enjoy Course to the Basic Course. The Melody List settings may need to be reprogrammed.
- Upon cancellation of a user's i-mode subscription or sp-mode subscription, their Melody Call subscription will also be revoked, and content registrations automatically cancelled. However, if any one of the following conditions applies, the Melody Call subscription will be maintained and content registrations to the Melody List continued, and charges will continue to apply.
 - When cancelling an i-mode subscription, a simultaneous sp-mode subscription is made on the same line.
 - When cancelling an sp-mode subscription, a simultaneous i-mode subscription is made on the same line.
 - When cancelling only either an i-mode or sp-mode subscription on a line that has both i-mode and sp-mode subscriptions.
- Due to usage rights or for other reasons, availability of some melodies (including melodies set to the Melody List) may cease without notice to the customer. In such instances, the ordinary ringback tone (typical ringing sound) will be played.
- Calls displaying "Caller ID Blocked" will activate the "My Usual Ringback Tone."

● Using in conjunction with other services

- When using Call Forwarding Service, playback of Melody Call may vary depending on whether or not Call Forwarding announcements are switched on or off, the type of phone to which the call is forwarded, and whether or not the Melody Call settings have been made.
 - When Multi number is being used, Melody Call plays for calls made to the basic subscription number, but not for calls made to additional numbers.*
 - Melody Call is not played for calls made from Videophones.*
- *The ordinary ringback tone (typical ringing sound) is played.

● Other Notes

- Subscription to Melody Call requires i-mode subscription or sp-mode subscription.
- Melody Call is not played during international calls or when WORLD WING is used. Instead, the ringback tone set by the overseas carrier is played.
- You cannot access the Settings Site, or sample or purchase melodies on an IP site while using international roaming services.
- mopera U cannot connect to the Melody Call Settings Site. Connecting via Wi-Fi requires a docomo ID and password.
- Selected melodies cannot be sampled when logging in with a docomo ID and password for a phone number other than the one you are using.
- When following procedures for transferring the subscription to another party, changing phone numbers, or suspending service, the Melody List, temporary deactivation and My Phonebook settings for the Melody Call function will be cleared. Users will need to re-enter these settings.
- This service is not available if you are subscribed to the FOMA·Xi Data Plan.
- Due to technical specifications, the portal melody confirmation button on the FOMA P2101V cannot be pressed. Dial *20001 to confirm the melody in Melody List 1, *20002 for the melody in Melody List 2, and *20003 for the melody in Melody List 3.
- An announcement is played when the subscriber is out of service range.
- In congested locations, the sound quality of Melody Call may vary depending on the condition of the signal.
- Melody Call may not be available for use in the event of damage to the phone system or communications regulations due to natural disaster.
- This service, or parts of this service, may not be available on some handsets.

● Actual screen may be different.